

FLAMMA

FT01

CLIP TUNER

Owner's Manual

Content

Precautions -----	01
Features -----	02
Instructions -----	03
Layout -----	04-05
Specifications -----	06

PRECAUTIONS

Please read carefully before proceeding

Power Supply

Please be sure to only use a 3V lithium button cell (Cr2032)

Important Safety Instructions

- 1.** Read these instructions
- 2.** Keep these instructions
- 3.** Heed all warnings
- 4.** Follow all instructions
- 5.** Do not use this apparatus near water
- 6.** Clean only with a dry cloth
- 7.** Do not install near any ventilation openings. Install in accordance with the manufacturer's instructions
- 8.** Do not install near any heat sources such as radiators, heat registers, stoves or other apparati (including amplifiers)that produce heat
- 9.** Do not defeat the safety purpose of the polarized or grounding-type plug. A polarized plug has two blades with one wider than the other. A grounding type plug has two blades and a third grounding prong. The wide blade of the third prong are provided for your safety. If the provided plug does not fit into your outlet consult an electrician for replacement of the obsolete outlet
- 10.** Protect the power cord from being walked on or pinched particularly at plugs, convenience receptacles, and the point

FCC certification

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- This device may not cause harmful interference
- This device must accept any interference received, including interference that may cause undesired operation


Features

1. Suitable for guitar and bass guitar
2. Fast, accurate tuning from 435 to 445Hz
3. 180° rotatable hinge
4. Power saving mode and automatic shutdown
5. Bright, colorful display

Instructions

- 1.** Attach the tuner to the headstock or body of your instrument. The clamp can be rotated up to 180° to find your preferred viewing angle
- 2.** Power on the tuner by pressing the power button.
- 3.** Press and hold the power button in the ON state to adjust the tuning frequency. When the screen displays "0", the tuner is set to 440HZ. You can adjust the frequency from "-5" to "+5" or 435Hz to 445Hz, by pressing the power button again. This mode will automatically exit after three seconds.
- 4.** Adjust the string to the target note as indicated on the pitch display. The note is in tune when both indicator LEDs are simultaneously lit up.
- 5.** The tuner will enter power saving mode after 10 seconds. After 2 minutes, FT-01 will turn off automatically.
- 6.** The user can power it off manually by pressing the power switch.

Layout



Instructions

01 Semitone Display:

Indicates if the note is a flat or sharp.

02 Accurate Pitch Display:

Displays the current string's target note. Both the upper and lower indicator LED light up simultaneously when correct pitch is achieved.

03 Power Switch:

Press switch to power on/off.

Press and hold to adjust the tuning frequency. It will automatically exit after 3 seconds.

04 Pitch Offset Display:

Indicates if the target note is sharp(above) or flat (below).

05 Screen:

The FTO1 tuner is gravity sensitive and the display will always adjust to face the proper direction, allowing you to mount it as you wish.

06 Pitch Display:

Indicates the target note.

07 Battery Compartment:

Use 3V lithium cell battery only.

08 Retaining Clamp:

Stable and durable metal fixture with 180° rotatable hinge.

Specification

Power requirements: 3V lithium cell (CR2032)

Dimensions: 57 mm(L)X27mm(W)X8mm(H)

Weight: 25g

Accessories: quick guide,Safety instruction&Warranty Card,Sticker,CR2032 Battery

